

# Firmware Release Notes

## Air Remote TTL-O

Firmware version: A2



### General notes

### Air Remote TTL-O (for Olympus)

The Air Remote TTL-O can be upgraded via the USB port. Be sure to not miss important upgrades on your product. Register your Air Remote TTL-O on [Profoto.com/register](http://Profoto.com/register) to receive first-hand information of future upgrades on your product.

This release notes covers firmware specific information. Detailed functionality descriptions are found in the user guide.

### New in firmware version A2

- Added hotshoe short circuit protection (quality enhancement).

### Check firmware version

Press ON to activate the remote, then press and hold the MODE button (upper right) for 10 seconds. When “Hello” is shown in the remote display, release finger from button and the firmware version will be displayed.

### Profoto flash compatibility

- Full functionality including TTL and HSS with Profoto AirTTL flashes.
- Full manual mode (Remote control and sync) excluding TTL and HSS with Profoto Air flashes.
- Sync only with Profoto AirS flashes.

### Olympus camera compatibility

- Check camera compatibility in Technical data on the product page for Air Remote TTL-O on [profoto.com](http://profoto.com).

